

Programmable Strip Cutter

Model: M-70

The SS Programmable Strip Cutter Model M-70 is a guillotine type programmable shear that can cut card or web stock into strips of desired width. This is a very rugged machine.

M-70 is run by an inbuilt microcomputer which can be easily programmed by a 4 key keypad and LCD display provided on the front panel.

120mm

1-12mm

220V, 50Hz

44cm X 38cm X 32cm (H)

40Kg

SPECIFICATIONS

Maximum Card

Width

Power

Weight

Dimension

Cut Width



FEATURES

- The cutting speed is about 5000 cuts per hour.
- The blades are easily replaceable and are made of hardened alloy steel.
- In normal operation, 1 million cuts can be made without the need for sharpening.
- The number of strip that are cut is programmable and can be varied as per requirement from 1 to 9999.
- The width of the strip is also programmable from 2mm to 12mm.
- The machine can cut laminate of width upto 12 cm.
- Keyboard entry for strip width definition.
- Emergency STOP switch.
- One-year warranty against manufacturing defect.

ORDERING INFORMATION

Programmable Strip Cutter Model M-70.

DST M70ZZZZ1029E

ADVANCED SENSOR SYSTEMS PVT. LTD.

20, INDUSTRIAL AREA, AMBALA CANTT – 133 006, INDIA TEL: +91-171-2699290/2699471/2699274, Website: www.mdimembrane.com Email: advancedsensorsystemsambala@gmail.com